



*Congratulations on the purchase of SPEED&BRAKE accelerating/braking system.
We wish You an advantageous use.
SPEED&BRAKE is very easy to use and extensively described in these instructions.
Read the use and maintenance instructions carefully before using the vehicle.*

Symbolism



NOTA BENE



PROCEDURE



ATTENTION – very important information

This manual is composed by 5 chapter, chapter 3 and 4 are dedicated to the use.

- | | |
|-------------------------------|-----------------|
| 1. General information | - Pag. 2 |
| 2. Safety | - Pag. 2 |
| 3. Use | - Pag. 3 |
| 4. What to do if... | - Pag. 6 |
| 5. Maintenance | - Pag. 7 |



Power supply 12 V

In compliance with all the characteristics regarding the DIRETTIVE MACCHINARI 2006/42/CE and the COMPATIBILITA' ELETTROMAGNETICA 2014/30/CE.

*Instructions based on a standard configuration, possible changes can be made according to the customer's requirements and the characteristics of the vehicle.
Handytech reserves the right to change the product without any forewarning.*

1. General information

By pushing the lever forward, SPEED & BRAKE allows you to slow or stop the vehicle via a telescopic shaft that connects the lever to the original brake pedal. Pulling the lever back accelerates the vehicle via a second telescopic shaft that connects the lever to the original accelerator pedal.

The pressure with which you push or pull on the lever allows you to gradually brake or accelerate.

The lever also has two buttons: a black one used as a horn and a red one used to lock the brake (as required by law); the latter allows you to lock the lever in the complete or partial brake position so you can move the gear lever.

The lever has an ergonomic knob to ensure solid grip.

The original brake and accelerator pedals can be used by able-bodied users.

2. Sicurezza

The system must only be used for the purposes it was created for; any other use is considered as improper.

CARROZZERIA 71 s.r.l. is not liable for any damage caused by incorrect system use.

Explain how SPEED & BRAKE works to anyone who will be working on your vehicle (dealer, body shop, mechanic, etc.) as well as anyone who will be using it.

If your vehicle needs maintenance or repairs, we recommend giving whoever is responsible for the work the phone number of the technician who installed the system for any clarifications.



If it is necessary to effectuate maintenance operations and repairs to the vehicle, we advise You to give to the operator the telephone number of the installer of the system for further indications.



It is advisable, after 2 years, in collaboration with Your local Handytech Centre, to check the status of the whole system and maybe to replace some parts.

Moreover, we remember to you, that out of the warranty period, the maintenance program is at Your discretion and risk, but the advice is to follow it carefully, because the negligence could cause malfunctions of the system and could create dangers during the utilization of the device.

Maintenance operations of the device during the warranty period and out the warranty period are to be borne by the customer.



The manufacturer guarantees the product for 24 months, only if the maintenance operations have been implemented by an authorized Handytech Centre.



While using SPEED&BRAKE, make sure that there are no objects (mat, etc.) between the pedals and the vehicle floor.

Also make sure that the sliding movement of the rods are not obstructed by objects for some reason.



The SPEED&BRAKE lever must never be used as a handhold, because it can create an excessive backlash of the system.

3. Use

□ Checks

Once the vehicle is turned on, make sure that the system works by pushing the lever forward (braking) and pulling back (accelerating).

Press the black button (*Photo 1*) to make sure that the horn works (after you've ascertained that you are not in an area where traffic laws do not allow it).



Photo 1



Photo 2

Press the red button to make sure that the brake lock (*Photo 2*) works.

The brake lock works by pushing the SPEED & BRAKE lever all the way and pressing the red button at the same time. Release the button before you stop pushing the lever.

When the lever is locked, you can use the vehicle's gear lever.

To release the SPEED & LOCK lever, simply push it forward and let it go.

❑ Moving the vehicle

After having run the checks, push the brake lever forward, press the red button and reduce pressure on the lever before releasing the red button.

At this point, the lever is locked and you can engage the gear.

Vehicle with automatic or sequential manual transmission

Move the gear lever from P or N to D (or other gear) or R, depending on the manoeuvre you need to make. Then push the lever again, which will automatically release the lock and allow you to move the vehicle.

When you first start using the system, we recommend trying several test brakes to get the hang of how much pressure to apply to the lever in order to brake gradually.



The vehicle **MUST** be stopped when you lock the brake.

❑ Use of the horn

Press the black button to sound the horn. Using the horn is subject to traffic laws.

❑ Stopping the vehicle

After using the vehicle and before turning it off, lock the brake as described previously, move the gear lever to P or N, pull the emergency brake, push the brake lever forward to release the lock.



The brake lock must not be used as an emergency brake, as the vehicle's original power brake or, in some cases, even the vehicle's braking system can have a drop in pressure that do not ensure the braking system is completely efficient when the vehicle is off. Furthermore, in some vehicles the brake lights stay on when the brake is pressed even when the key is removed.

❑ Able-bodied people using the vehicle





The vehicle's original brake and accelerator can be used normally with your feet.

Let the user know about the SPEED & BRAKE system as, in some cases, as shown in *Photo 3*, it can partially interfere with the normal driving movements of an able-bodied user.



Photo 3

What to do if ...

1. After starting the vehicle's engine, the lever is in a markedly forward position and is very hard to push
 Make sure you haven't accidentally left the lever locked: if you have, release it.
2. The brake lock does not engage when the red button is pressed
 There may be an issue with the lock's electrical system or a mechanical issue; go to a Handytech Centre to repair the problem.
3. The horn does not sound when the black button is pressed
 Make sure the vehicle's original fuse is intact. If necessary, replace it with one having the same amperage. Should the problem persist, go to a Handytech Centre.
4. As you use the lever, you notice it has an idle stroke from its home position to when it starts braking.
 Go to a Handytech Centre for calibration.



If your system has a problem that is not listed, you must contact your nearest Handytech Centre.

MAINTENANCE TO BE CARRIED OUT SOLELY AT HANDYTECH CENTRES

First check: Km. 1,500

- ☐ Check if the horn is properly working.
- ☐ Check the brake drum operation.
- ☐ Check locking and sliding.
- ☐ Check the various parts for proper tightness and irregular play.
- ☐ Make sure the lever properly rotates on its rotating pin.
- ☐ Check the ball joints at the ends of the telescopic shaft and lubricate them (*Photo 4*).




Photo 4

- ☐ Check the ball joints for proper sliding and lubricate them.
- ☐ Make sure braking is correct. Adjust if necessary.
- ☐ Make sure acceleration is correct. Adjust if necessary.
- ☐ **Check for proper operation as the vehicle is moving.**

Subsequent checks

KM. 25,000 (or after 8 months)

- ☐ Repeat the checks carried out after 1500 km.
- ☐ **Check for proper operation as the vehicle is moving.**

KM. 50,000 (or after 16 months)

- ☐ Repeat the checks carried out after 1500 km.
- ☐ In some cases of wear, it is advisable to replace the ball joint that connects the telescopic shaft to the brake pedal.
- ☐ **Check for proper operation as the vehicle is moving.**

KM. 75,000 (or 24 months)

- ☐ Repeat the checks carried out after 1500 km.
- ☐ **Check for proper operation as the vehicle is moving**

100,000 - 125,000 - 150,000 km or at least once a year

- ☐ Repeat the checks carried out after 1500 km.
- ☐ It is advisable to check the conditions of the parts that are subject to wear (joint balls, sliding rods, etc.), and replace them if necessary.
- ☐ **Check for proper operation as the vehicle is moving**

Km 175,000 and more

- ☐ Repeat the checks carried out after 1500 km.
- ☐ It is also advisable, along with your trusted Handytech Centre, to check the system condition and replace any parts that need to be replaced.
- ☐ **Check for proper operation as the vehicle is moving**

NOTE:

After 2 years, it is also advisable, along with your trusted Handytech Centre, to check the system condition and replace any parts that need to be replaced

We remind you that once the warranty expires, the maintenance program is at your discretion, but we recommend following it scrupulously, as neglecting it could cause system anomalies and inconveniences, in addition to being dangerous while driving.

Any maintenance work on the device shall be fully borne by the customer both when the device is covered by warranty and not.

WARRANTY: 24 MONTHS**SPACE FOR THE INSTALLER**

Notes of the installer

Further useful information

		RETRO	
SX	DX	SX	DX
8	1	2	7
6	3	4	5